

ReSound Unite™ Mini Microphone



ReSound



rediscover hearing

Welcome

Congratulations on your purchase of a ReSound Unite™ Mini Microphone, a high quality streamer of speech and sound.

ReSound Unite™ Mini Microphone streams speech directly to your hearing instrument.

The line-in functionality of the Mini Microphone will provide you with a streamed audio signal (mono) from your audio system, personal computer, TV or similar device directly to your hearing instruments.

Please read this manual carefully to fully benefit from the ReSound Unite™ Mini Microphone. Ask your Hearing Healthcare Professional if you have any questions.

For further information you can also visit the www.gnresound.com/unite website.

For your safety, carefully read the chapter "Important Information," starting on page 23.

FCC ID: X26SM-1

Statement

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the Mini Microphone and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications can void the user's authority to operate the equipment.

Intended use

ReSound Unite™ Mini Microphone is intended to enable ReSound hearing instrument users to better follow speech or listen to other audio signals. The essential performance of the ReSound Unite™ Mini Microphone is to transfer signals from the microphone or other audio devices to a ReSound wireless hearing instrument.

List of countries

Products are intended for sale in countries within the European Economic Area as well as Switzerland.

National restrictions

Norway: You are not allowed to operate the equipment within 20 km of the centre of Ny Ålesund.

France: You are not allowed to operate the equipment outdoors.

Italy: Product is for private use. You are not allowed to operate the equipment outside your own premises.

This product is in compliance with the following regulatory standards:

In EU: The device conforms to the essential requirements according to - Annex I of Council directive 93/42/EEC for medical devices (MDD) and essential requirements and other relevant provisions of directive 1999/5/EC (R&TTE). The declaration of conformity may be consulted at www.resound.com

In US: FCC CFR 47 Part 15, subpart C, section 15.247

In Canada: IC 6941C-SM1

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

For other identified applicable international regulatory requirements in countries outside EU and US, please refer to local country requirements.

Products are categorized as receiver class 2 according to EN 300 328.

Contents

Description 8

Getting started 10

Turning your ReSound Unite™ Mini Microphone
ON and OFF 11

Pairing to your hearing instruments. 12

Start streaming 15

Stop streaming 17

Wearing your ReSound Unite™ Mini Microphone 18

Light indicator (LED) 18

Using the line-in input 19

Volume control 21

Important information 23

General warnings 24

General precautions 25

Technical specifications 31

Warranty 32



Troubleshooting guide 34

Description

1. Mini-USB connector for charging
2. Microphone inlet
3. Line-in input
4. ON/OFF switch



5. Volume control
6. Light indicator (LED)
7. Clip
8. Pairing button



Getting Started


Charging the Battery

Before using your ReSound Unite™ Mini Microphone, you need to fully charge the rechargeable battery. To charge it, plug the charging cable as shown in the picture to the right. Then plug the other end of the charging cable into a power outlet.


During the charging process, the LED indicator will show a solid red light. When fully charged and still connected to the charger, the LED will turn solid green interrupted by a red blink every 2 seconds.

Charging an empty battery typically takes about 3 hours. It is safe to leave the charger connected overnight—the battery cannot be overcharged.

- When charging your ReSound Unite™ Mini Microphone for the first time, allow it to charge for at least 3 hours, even if the battery indicator indicates that the battery is fully charged.



- For safety reasons, recharge the battery only with chargers supplied by ReSound.



Do not charge the Unite Mini Microphone while it is on your body.

Turning your Mini Microphone ON and OFF

To turn ON your ReSound Unite™ Mini Microphone, slide the ON/OFF switch (#4 on page 8) down to the ON position. A white “I” icon will be visible on the switch and the LED indicator will now blink green every 2.5 seconds.

If the battery level is low the LED will blink yellow every 2 seconds.

To turn it OFF, slide the ON/OFF switch up to the OFF position. The LED will now stop blinking.

Pairing to your hearing instruments




Note! The following information is intended primarily for your Hearing Healthcare Professional, who in most cases will complete the tasks that are necessary before the ReSound Unite™ Mini Microphone can be used with your hearing instruments. However, the process is designed to be simple and most people can do it themselves.

It is possible to pair up to three ReSound Unite™ streaming devices—e.g. one Mini Microphone and two TV streamers (an optional ReSound Unite™ accessory)—with a given pair of hearing instruments. Therefore, channel 1, 2 or 3 must be selected when starting the pairing process.

Pairing the Mini Microphone in Channel 1

1. Make sure ReSound Unite™ Mini Microphone is turned ON. Your hearing instruments must be OFF—the battery doors must be open.
2. Remove the silver cap from the Mini Microphone. With the tip of a pen or similar object, press the small pairing button one time on the front of your ReSound Unite™ Mini Microphone (see picture on the next page). The LED will now blink yellow once every 2 seconds to indicate that it is ready to be paired in Channel 1. Your ReSound Unite™ Mini Microphone will remain in pairing mode for 20 seconds.



3. While pairing mode is activated, close the battery doors of both hearing instruments and make sure they are ON. A successful pairing will be indicated by an audible melody played in both hearing instruments.

You are now ready to use the ReSound Unite™ Mini Microphone!

Pairing the Mini Microphone in Channel 2 or 3

To pair the Mini Microphone in Channel 2, press the pairing button twice. The LED will now blink yellow twice every 2 seconds to indicate that it is ready to be paired in Channel 2. Close the battery doors on the hearing instruments.

To pair the Mini Microphone in Channel 3, press the pairing button three times. The LED will now blink yellow three times every 2 seconds to indicate that it is ready to be paired in Channel 3. Close the battery doors on the hearing instruments.

Pairing blinking pattern:

Pairing button pushes	LED blinking pattern				Channel
1	①	①	①	①	1
2	① ②	① ②	① ②	① ②	2
3	① ② ③	① ② ③	① ② ③	① ② ③	3

Start streaming

Turn on the Mini Microphone and make sure your hearing instruments are turned on as well. Streaming may then be started in one of two ways.

1. Press and hold the push button on both hearing instruments for about three seconds in order to listen to the streamed audio signal. Once ReSound Unite™ Mini Microphone has been connected, an audible melody will play in your hearing instruments and will be followed by the streamed sound.
2. If you have a ReSound Unite™ Remote Control (optional), simply press the Unite™ streaming button. Doing so will briefly show a search icon in the remote control display. Once the hearing instruments connect to ReSound Unite™ Mini Microphone, a short melody will be played in both ears to confirm the presence of streamed audio and a streaming icon will appear in the display. The streamed sound can now be heard in your hearing instruments.

Start streaming on a 2nd or 3rd ReSound Unite™ Mini Microphone unit

If your hearing instrument is paired to more than one streaming device, you can start streaming in two ways.

1. Press and hold the hearing instrument push button for about 3 seconds a 2nd or 3rd time to access the 2nd or 3rd ReSound Unite™ streaming device.
2. If you use a Unite™ Remote Control, press the streaming button on the Unite™ Remote Control a 2nd or 3rd time to access the 2nd or 3rd ReSound Unite™ streaming device.



Searching for
Mini Microphone



Connected to
Mini Microphone

Streaming button



When using the Unite Remote Control, listening programs for streaming devices are designated as A, B and C.* The program in use is indicated in the remote control display.

** The designations for listening programs can be customized by your hearing healthcare professional in the programming software. Such customizations will be reflected in the remote control display.*

Stop streaming

- To stop streaming with the ReSound Unite™ Remote Control (optional) you just have to press the “P” button, located in the center of the key pad. This will return the hearing instruments to the last program used. You may also press the home button to return to your default settings.
- If you are using the telephone with the ReSound Unite™ Phone Clip or with PhoneNow™, streaming of the ReSound Unite™ Mini Microphone will be temporarily disrupted. When you have ended your phone call, streaming will resume.










Note! The Mini Microphone will transmit over a range of approximately 20 feet (or more.) Transmission can be interrupted if the distance between the hearing instrument and the Mini Microphone is increased beyond the transmission range. If the Mini Microphone is moved back into range within 5 minutes, your hearing instruments will automatically reconnect and continue streaming.

Wearing your ReSound Unite™ Mini Microphone

Clip your ReSound Unite™ Mini Microphone on the speaker's jacket or other clothing. Place the device within a range of 4 to 8 inches from the speaker's mouth.

Light indicator (LED)


The Light indicator (#6 on page 9) on your ReSound Unite™ Mini Microphone serves as a multipurpose user interface, providing information on the status of your device.

Blinks	Meaning
	Normal operation
	Battery low
	Charging
	Fully charged – still connected to charger
	Pairing in channel 1
	Pairing in channel 2
	Pairing in channel 3

Using the line-in input

The line-in input (#3 on page 8) can be used to stream audio signals from most audio devices through the ReSound Unite™ Mini Microphone's line-in feature directly to your hearing instrument.

1. Insert one end of the cable included with your ReSound Unite™ Mini Microphone into the line-in jack on the Mini Microphone.
2. Plug the other end of the cable into the AUDIO OUT on the audio device you want to stream from.





Note: When using the ReSound Unite™ Mini Microphone with a TV, you can use the HEADPHONE output terminal which is usually located on the side or front of the TV. Typically, when using the HEADPHONE output terminal on the TV, only the person wearing the hearing instruments will hear the sound, and the TV speakers will be muted. Consult your TV manual to determine whether or not your TV supports simultaneous speaker and HEADPHONE use.

Volume control

ReSound Unite™ Mini Microphone has been designed to provide a comfortable listening level from the moment it is activated. However, for some devices or listening environments it may be desirable to adjust the listening volume. This can be accomplished in a variety of ways. Keep in mind that volume adjustments apply to the streamed signal only, not the volume of normal environmental sounds.

- Use the “+” and “-” keys (#5 on page 9) to adjust the volume to a comfortable level. Make sure that the volume on your hearing instruments is set to a comfortable level before you adjust the setting on your Mini Microphone.



Note: When using the Mini Microphone as a microphone the last volume setting will be stored. When using the line-in, the volume setting will revert to the default level when the Mini Microphone is turned OFF and ON again to avoid an uncomfortable loud initial sound level when used with different audio sources.

- Use the Resound Unite™ Remote Control (optional) to adjust the streaming volume in the hearing instrument. Ask your Hearing Healthcare Professional for more information about this accessory.
- In some cases, the volume can be further adjusted at the signal source, for example by turning down the volume on the TV itself. In many cases this will adjust the volume of both streamed audio (transmitted wirelessly to your hearing instruments) and non-streamed audio (sounds reaching the hearing instrument microphones in the normal fashion). Of course, this will also affect listening volume for others in the room.

Important information



Maintenance and Care

- Clean the ReSound Unite™ Mini Microphone using a damp cloth. Never use household cleaning products (detergent, soap, etc.) or alcohol to clean the device.
- When the ReSound Unite™ Mini Microphone is not in use, turn it OFF and store it safely.
- Protect the ReSound Unite™ Mini Microphone from excessive moisture (bathing, swimming) and heat (radiator, car dashboard). Protect it from excessive shock and vibration.
- Protect the microphone and charger inlets from debris and dirt. If necessary, use the cleaning brush provided with your hearing instruments to clean these areas.

General warnings



- Young children can wrap cords and lanyards /keychains around their neck causing the risk of strangulation. Therefore, always keep cords and lanyards /keychains out of reach of children.
- The ReSound Unite™ Mini Microphone uses low-powered digitally coded transmissions in order to communicate with other wireless devices. Although unlikely, nearby electronic devices may be affected. In that case, move the ReSound Unite™ Mini Microphone away from the affected electronic device.
- If your ReSound Unite™ Mini Microphone is affected by electromagnetic interference, move it away from the source of interference.
- Avoid exposing your product to rain, moisture or other liquids to protect against damage to the product or injury to you.
- Keep the product and any cords and cables away from operating machinery.
- If the product overheats, has been dropped or damaged, has a damaged cord or plug, or has been dropped in a liquid, discontinue use and contact your Hearing Healthcare Professional.
- Dispose of the product according to local standards and regulations.

- Do not use in areas where there are explosive hazards.

Ignition of flammable atmospheres

- Do not use the product in environments where there is a danger of ignition of flammable gasses

General precautions



- Do not use this device in locations where it is forbidden to use electronic devices.
- X-ray radiation (e.g., CT scans, MRI scans) may adversely affect the correct functioning of this device. We recommend that you switch the device OFF before undergoing X-ray procedures and keep it outside the room.
- High-powered electronic equipment, larger electronic installations and metallic structures may impair and significantly reduce the operating range.
- If the hearing instruments do not respond to the device because of an unusual field disturbance, move away from the disturbing field.
- Your hearing instruments and this device were given a unique communication code during the fitting. This ensures that the device will not affect hearing instruments worn by others.

- Do not make any changes or modifications to this device.
- Opening the ReSound Unite™ Mini Microphone might damage it. If problems occur which cannot be resolved, consult your Hearing Healthcare Professional.
- The ReSound Unite™ Mini Microphone may only be repaired by an authorized service center.
- Do not use the ReSound Unite™ Mini Microphone in areas where RF transmission is prohibited, e.g., airplanes, etc.
- Only connect your ReSound Unite Mini Microphone to the cables provided with the device.

BUILT-IN BATTERY CARE: Please observe the following if the product contains a battery



- Your product is powered by a rechargeable battery.
- The full performance of a new battery is achieved only after two or three complete charge and discharge cycles.
- The battery can be charged and discharged hundreds of times, but will eventually wear out.
- Unplug the charger from the electrical outlet as well as the Mini Microphone when not in use for extended periods of time.
- If left unused, a fully charged battery will lose its charge over time.
- Leaving the product in hot places, such as in a closed car in the summer conditions, will reduce the capacity and lifetime of the battery.
- A product with a cold battery may not work temporarily, even when the battery is fully charged. Battery performance is particularly limited in temperatures well below freezing.

Battery warning!



- “Caution”—The battery used in this product may present a risk of fire or chemical burn if mistreated.
- Do not attempt to open the product or replace the battery. It is built-in and not changeable. Use of other batteries may present a risk of fire or explosion and the warranty will be terminated.
- The battery in your product cannot be removed or replaced by the user. Any attempt to do so is risky and may result in damage of the product.
- Only recharge the ReSound Unite™ Mini Microphone with a power supply unit that has been supplied with the product.
- Dispose of batteries according to local regulations. Please recycle when possible.
- Do not dispose the battery as household waste or in a fire as it may explode.
- Batteries may explode if damaged.

CHARGER CARE: Please observe the following if the product is supplied with a charger



- Do not attempt to charge your product with anything other than the AC adapter provided. The use of any other types may damage or destroy the product and could be dangerous. Use of other chargers may invalidate any approval or warranty.
- For availability of approved enhancements, please check with your Hearing Healthcare Professional.
- Charge the product according to the instructions supplied with the product.

Charger warning!



- When you disconnect the power cord or any connected devices, grasp and pull the plug, not the cord.
- Never use a charger that is damaged.
- Do not attempt to disassemble the charger as it may expose you to dangerous electric shock.
- Incorrect reassembly can cause electric shock or fire when the product is subsequently used.
- Avoid charging your product in extremely high or low temperatures and do not use the charger outdoors or in damp areas.
- Do not charge the ReSound Unite™ Mini Microphone while it is on your body.

Technical specifications

Operating range:	up to 20 feet or more
Power supply:	External wall adapter
Wireless	2.4 GHz
Operating temperature:	32° to 113° F
Storage temperature:	-4° to 113° F

Temperature test, transport and storage information

The product is subject to various tests in temperature and damp heating cycling between -13° F and 158° F according to internal and industry standards.

Warranty

The ReSound Unite™ Mini Microphone is covered by a limited warranty issued by the manufacturer for a period of 12 months from the day of the original purchase. Please notice that extended warranties may apply in your country. Please contact your local Hearing Healthcare Professional for more information.

What is covered by this warranty?

Any electrical component that, because of workmanship, manufacturing or design defects fails to function properly under normal use during life of this warranty will be replaced or repaired at no charge for parts or labor when returned to the point of purchase.

If it is determined that repair is not feasible, the entire unit may be replaced with an equivalent unit upon mutual agreement of the Hearing Healthcare Professional and the customer.

What is not covered by this warranty?

Problems arising from improper handling or care, excessive use, accidents, repairs made by an unauthorized party, exposure to corrosive conditions or damage due to foreign objects entering the device are NOT covered by the limited warranty and may void it. The above warranty does not affect any legal rights that you might have under applicable national legislation governing sale of consumer products. Your Hearing Healthcare Professional may have issued a warranty that goes beyond the clauses of this limited warranty. Please consult your Hearing Healthcare Professional for further information.

Serial number: _____

Date of purchase: _____

TROUBLESHOOTING GUIDE

SYMPTOM	CAUSE	POSSIBLE REMEDY
<i>The streaming button on the Remote Control is pressed but with no effect at all</i>	The Unite Mini Microphone and hearing instruments have not been paired	Carry out pairing process
	The Remote Control and hearing instruments are not within wireless range	Assure that Remote Control and hearing instruments are within wireless range and activate streaming again
<i>The push button on the hearing instrument has been pressed for more than 3 seconds but with no effect at all</i>	The Unite Mini Microphone and hearing instruments have not been paired	Carry out pairing process
<i>The pairing button on the Unite Mini Microphone is pressed but no pairing melody is played in the hearing instrument</i>	The Unite Mini Microphone and hearing instrument are not within wireless range	Assure that Unite Mini Microphone and hearing instruments are within wireless range and repeat pairing process
	The Unite Mini Microphone and hearing instrument have not been simultaneously in pairing mode	Repeat pairing process and assure that the battery doors on both hearing instruments are closed within 20 seconds after the pairing button has been pressed on the Unite Mini Microphone

TROUBLESHOOTING GUIDE

SYMPTOM	CAUSE	POSSIBLE REMEDY
<i>The streaming button on the Remote Control is pressed but no streamed audio signal is found when searched for (indicated by an "X" icon on the display)</i>	The Unite Mini Microphone and hearing instrument are not within wireless range	Assure that Unite Mini Microphone and hearing instruments are within wireless range and activate streaming again
	The Unite Mini Microphone is not powered on	Power on the Unite Mini Microphone and activate streaming again
	The battery level of the Unite Mini Microphone is too low to support streaming	Charge the battery
	An audio device has been connected to the line-in jack but the device is powered off or the output has been muted	Power on or unmute the external audio device

TROUBLESHOOTING GUIDE

SYMPTOM	CAUSE	POSSIBLE REMEDY
<i>There is no sound from the hearing instruments despite being in a streaming program</i>	The Unite Mini Microphone and hearing instrument are out of wireless range	Assure that Unite Mini Microphone and hearing instruments are within wireless range again
	The Unite Mini Microphone is no longer powered on	Power on the Unite Mini Microphone and activate streaming again
	The battery level of the Unite Mini Microphone has become too low to support streaming	Charge the battery
	An audio device has been connected to the line-in jack but the device has been powered off or the output muted	Power on or unmute the external audio device

TROUBLESHOOTING GUIDE

SYMPTOM	CAUSE	POSSIBLE REMEDY
<i>A hearing instrument unintentionally drops out of the streaming program</i>	At least one of the causes described for the “no sound” symptom above has persisted for more than 5 minutes	Take the necessary corrective action as described for the “no sound” symptom above and activate streaming again
	The battery in the hearing instrument is so depleted that it no longer supports audio streaming	Replace the battery in the hearing instrument with a new one, and activate streaming again
<i>The sound from the Unite Mini Microphone is too high or is distorted</i>	An audio device has been connected to the line-in jack and the audio level from this device is too high	Adjust the volume using the “+” and “-” keys on the Unite Mini Microphone, or using the volume control on the external audio device itself, until the best sound level and quality is obtained.

TROUBLESHOOTING GUIDE

SYMPTOM	CAUSE	POSSIBLE REMEDY
<i>The sound level from the Unite Mini Microphone is very low</i>	The Unite Mini Microphone is not worn correctly by the speaker	Clip the Unite Mini Microphone on the speaker's jacket or other clothing or hang it around the speaker's neck using the lanyard, so that the device is within 4 to 8 inches from the speaker's mouth
	The sound received by the microphone is very low	Increase the volume using the "+" key on the Unite Mini Microphone
	An audio device has been connected to the Line-in jack and the audio level from this device is too low	Adjust the volume using the "+" and "-" keys on the Unite Mini Microphone, or using the volume control on the external audio device, until the best sound level and quality is obtained.

TROUBLESHOOTING GUIDE

SYMPTOM	CAUSE	POSSIBLE REMEDY
<i>The sound from the Unite Mini Microphone is still either too low or too high</i>	The audio volume level of the hearing instruments is not suitable for listening	Adjust the volume either on the hearing instruments themselves (if provided with a volume control), or alternatively, using the “+” and “-” keys on the Remote Control
<i>The sound from the Unite Mini Microphone is distorted or drop-outs occur frequently</i>	The Unite Mini Microphone and hearing instruments are on the edge of the wireless range	Assure that Unite Mini Microphone and hearing instruments are within wireless range
	The Unite Mini Microphone and hearing instruments are not within sufficient “line-of-sight”	Assure that no significant obstacles will obstruct the hassle-free streaming from the Unite Mini Microphone to the hearing instruments

Be aware of information marked with the warning symbols:



WARNING points out a situation that could lead to serious injuries,
CAUTION indicates a situation that could lead to minor and moderate injuries



Advice and tips on how to handle your ReSound Unite™ accessory better.



Equipment includes RF transmitter



Product is a Type B applied part



Please ask your local Hearing Healthcare Professional concerning disposal of your ReSound Unite accessory



Any issues relating to the EU Medical Device Directive 93/42/EEC and R&TTE Directive 1999/5/EEC should be directed to GN Hearing A/S, Lautrupbjerg 7, DK 2750 Ballerup, Denmark

Manufactured by:

ReSound North America

8001 Bloomington Freeway
Bloomington, MN 55420
phone: 1-888-735-4327

Government Services
1-800-392-9932
VAinfo@gnresound.com

ReSound Canada

303 Supertest Road
Toronto, Ontario M3J 2M4
phone: 1-888-737-6863

gnresound.com
consumerhelp@gnresound.com

17729511 US 8/11 Rev A

ReSound



rediscover hearing